



STEP 1
LIFT SEAT



STEP 2
LOCATE THREADED NUTSERTS AS SHOWN ABOVE.



STEP 3
LINE UP DOOR STOP MOUNTING HOLES WITH THE THREADED NUTSERTS AS SHOWN.



STEP 4
FASTEN DOOR STOP USING THE SUPPLIED 1/4-20 X 3/4" SCREWS.

DOOR STOP INSTALLATION
PROTOTYPE PARTS SHOWN.

GEARGRID		NAME	DATE	TITLE:
DRAWN		LUKEB.	05/06/2020	DOOR STOP INSTALL
ENGINEER		UNLESS OTHERWISE SPECIFIED:		
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF GEARGRID CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF GEARGRID CORPORATION IS PROHIBITED.		DIMENSIONS ARE IN INCHES		
INTERPRET DIM AND TOLERANCE PER ASME Y14.5M-1995		TOLERANCES:		
THIRD ANGLE PROJECTION		ANGLE MACHINED ±.5°		
		ANGLE FORMED ±1°		
		TWO PLACE .XX ±.03		
		THREE PLACE .XXX ±.010		
		HOLE Ø ±.005		
FINISH		MATERIAL		
SIZE		PART NO.		REV
D				01
DO NOT SCALE DRAWING SHEET 1 OF 1				